

Mod. R&S. 05/0 Pag. 1/1

Last Updating: 10/2008

P.S. FILM EXTRA

Cad-cut material for difficult fabrics

Description

PVC-free material for Cad-Cut ® applications. Suitable for "difficult" fabrics such as nylon jackets, sportswear, bags, umbrellas and leather.

Adhesive Polyester backing.

Basic Information

Due to the many different base materials available on the market, the following heat transfer instructions are given as guideline only:

Temperature: 160°C

Time: 15"
Pressure: min.

Application Instructions

Important:

- 1) Cut the material in reverse
- 2) Weed the exceeding material
- 3) Place the material on the garment with its polyester support
- 4) Heat apply
- 5) Remove polyester backing **hot**

Suitable for

Polyamide, nylon and silicon treated garments not dyed with sublimation inks

Washing: (wait 24h after the heat transfer)

40°C Max. – do not use bleach or other aggressive chemical agents

Dry-cleaning: no **Tumble drier:** yes

N.B.: all information given in this sheet are based on our experience

We recommend to always perform a test before starting standard production

The product meets the Italian and Ue regulations relating to its proper use. This document can be subject to variations. Updated versions are available on our website www.siser.it. For further information, please contact our Sales Office. Thank you.





